

# STICKLERS™ **Application Note**



When You Need Perfectly Clean Fiber Splices and Connectors

## Cleaning Fiber Optic Ports



1

### Tools You Need

Every fiber optic connector should be cleaned every time it is mated, tested or reconfigured. Select the Stickler™ CleanStixx™ lint-free swabs which are engineered specifically for fiber optic connectors. The “S25” model is for SC, FC, ST and similar sizes (#MCC-S25); the smaller “S12” is for LC and MU configurations (#MCC-S12). Since wet-dry cleaning produces the best results, also select the Sticklers™ Fiber Splice and Connector Cleaner fluid (#MCC-POC03M). This is a nonflammable fluid that replaces old-style alcohol cleaners.



2

### Select the Cleaning Stick

[Photo 1] Begin by removing one CleanStixx™ from the package. Be careful not to contaminate the tip by touching it. Re-seal the bag to avoid contaminating remaining sticks.

### Dampen the Nib or Cleaning Tip

[Photo 2] Pick up the solvent, tilt it back slightly and slowly depress the dispenser to fill the “well” with solvent. Dip the CleanStixx™ briefly — damp is good, wet is bad. (A saturated tip cannot absorb contaminants).



3

### Cleaning UPC Connectors (SC, ST, FC, LC, MU)

[Photo 3] Insert the CleanStixx™ into the alignment sleeve. Vary the pressure on the end-face, pushing back on the spring slightly. Rotate the CleanStixx™ five times in the same direction. Remove, discard and inspect.

### Cleaning APC Connectors (ASC, AFC)

[Photo 4] Insert the CleanStixx™ into the alignment sleeve, gently varying the pressure while rotating it 1/4 turn back and forth five times, allowing the CleanStixx™ to conform to the end-face and clean the entire surface. Remove, discard and inspect.



4

### Products

Fiber Optic Splice and Connector Cleaner

3 oz. / 85 g

MCC-POC03M

CleanWStixx™ Swabs

50 Stixx/bag

Varies by connector size

TRADEMARKS: The term “Sticklers”, “CleanStixx”, “CleanWipe”, “CleanSlots”, “TravelSAFE”, and “Triton” are all trademarks of MicroCare Corp. The MicroCare name and logo are registered trademarks of MicroCare Corp. US patents #7,401,374; #7,685,668 and #7,784,647 allowed. Additional patents applied for and pending.

DISCLAIMER: The information set forth herein is based on data believed to be reliable, but MicroCare makes no warranties express or implied as to its accuracy and assumes no liability arising out of its use by others. This publication is not to be taken as a license to operate under, nor to infringe upon, any patents not herein expressly described.



Above: Fingerprint oils on a connector end-face.



Below: A properly cleaned connector end-face

### Sticklers™ Cleaners by MicroCare

595 John Downey Drive, New Britain, CT 06051 USA

Tel: 860.827.0626 Fax: 860.827.8105

In North America, Dial: 800.638.0125

Email: TechSupport@SticklersCleaners.com

Learn More at: [www.SticklersCleaners.com](http://www.SticklersCleaners.com)